

Rebooting the NUC

If the NUC within the the Pod is showing as offline,
it will need to be rebooted.

Below are the instructions that need to be followed to perform this action.



Step 1: Accessing the NUC.

You should find a Sarel enclosure box located near the access point. You can unlock it using the key provided by MSite or, alternatively, with a flat-head screwdriver.



Step 2: Resetting the NUC.

Inside the enclosure, you should find the NUC, a black box with an on/off switch. There are two different models used depending on your configuration.
Below, you can see the locations of the on/off switch for each model.



Please make sure that this device is powered on and in the 'on' position. If it is already on, please restart it using the same button.

